

MAGNA SBG1P-OH

STRONG BASE ANION

TYPE I ANION
POLYSTYRENIC POROUS GEL
HYDROXIDE FORM

ResinTech SBG1P-OH is a hydroxide form type 1 porous gel strong base anion resin. Its higher moisture content and lower ion exchange density result in higher operating capacity, greater efficiency, and improved resistance to fouling. It can follow a water softener to remove silica and other anions but is especially well suited for use in all types of deionizing systems, particularly mixed beds.

APPLICATIONS

- Demineralization
- Anion Component in Mixed Beds

TYPICAL PROPERTIES & PHYSICAL CHARACTERISTICS

Polymer Matrix	Styrenic Porous Gel
Ionic Form	Hydroxide
Functional Group	Trimethylamine
Physical Form	Spherical Beads
Particle Size	16 to 50 US Mesh (297 - 1190 µm)
% < 50 mesh (300µm)	< 1%
Minimum Sphericity	93%
Uniformity Coefficient	1.6
Reversible Swelling	OH to Cl -20% to -28%
Temp Limit	140°F (60°C)
Capacity (meq/mL)	1.05
Moisture Retention	52% to 60%
Shipping Weight	41 - 43 lbs/ft ³ (657 - 689 g/L)
Color	Yellow to Orange
Regenerability	Yes

PACKAGING OPTIONS

- 1 ft³ bags
- 1 ft³ boxes
- 1 ft³ drums
- 7 ft³ drums
- 42 ft³ supersacks

Revision 1.0
ResinTech, Inc.®





MAGNA

SBG1P-OH

STRONG BASE ANION

TYPE I ANION
POLYSTYRENIC POROUS GEL
HYDROXIDE FORM



SUGGESTED OPERATING CONDITIONS

Maximum continuous temperature	
Hydroxide form	140°F
Minimum bed depth	24 inches
Backwash expansion	25 to 50 percent
Maximum pressure loss	20 psi
Operating pH range	0 to 14 SU
Regenerant Concentration	
Hydroxide cycle	2 to 6 percent NaOH
Salt cycle	2 to 10 percent NaCl
Regenerant level	4 to 10 lbs./cu.ft.
Regenerant flow rate	0.25 to 1.0 gpm/cu.ft.
Regenerant contact time	>40 minutes
Displacement flow rate	Same as dilution water
Displacement volume	10 to 15 gallons/cu.ft.
Rinse flow rate	Same as service flow
Rinse volume	35 to 60 gallons/cu.ft.
Service flow rate	1 to 10 gpm/cu.ft.

Note: These guidelines describe average low risk operating conditions. They are not intended to be absolute minimums or maximums. For operation outside these guidelines, contact ResinTech Technical Support

Revision 1.1
 ResinTech, Inc.®

